

The Scotts® Advantage:

 Scotts®Drop Spreader provides superior accuracy for consistent greening and complete coverage

.....

 Holds up to 10,000 sq. ft. of Scotts® Lawn Products (fertilizer, seed, granulars)


On/off trigger ———

Precision rate control – (to set spreader)

Wingnuts -

Rustproof hopper






Set Up:


Brace -U-Bar -

1. Lay the spreader down so that it rests on the front of the hopper.

••••••

- **2.** Lift the U-bar and brace, then spread the sides of the brace and insert the ends into the holes in the U-bar.
- **3.** Place the spreader upright on its wheels.
- **4.** Raise the top half of the handle to the upright position and hand tighten the wing nuts.







Scotts®Turf Builder® Drop Spreader

Quick Start Instructions:


 Fill hopper with Scotts® lawn product of your choice



4. When finished, sweep any stray particles from hard surfaces back onto lawn area.




2. Turn rate control to correct setting listed in the Spreader Setting section on the back of each package of Scotts product under "Scotts" Drop Spreaders"



5. Never leave product in the spreader. Pour leftover material back into the package and seal the package tightly



3. To apply product, begin walking at a steady pace (approx. 4ft./sec.), then squeeze and hold trigger (See diagrams below)




After each use, wash thoroughly over the lawn to remove all material clinging to the spreader. Hot water may be required at times to remove stubborn residue. Allow the spreader to dry thoroughly in the sun.

Store your spreader in a clean dry place.

Application Tips

For Rectangular Lawns:


Apply two header strips across each end for a turning area. Then apply back and forth in the longest direction.



Header Strip

For Irregular-Shaped Lawns:

Apply one header strip around the entire lawn for a turning area, then apply back and forth.



Header Strip

Spreader Overlap:

To avoid streaks or misses, overlap spreader patterns approximately 1-1/2 feet (50cm). Do not leave spreader open when making turns.

